CREATIVE INNOVATION GRAND PRIZE IN 2015

MINISTRY OF SCIENCE, ICT AND FUTURE PLANNING IN 2015



DID YOU STERILIZE YOUR AIR?

IT IS DIFFERENT BETWEEN FILTERING AND STERILIZING AIR.

COMPLETELY REMOVE HARMFUL SUBSTANCES


100% no hazard to human Ozone emission rate is lower than the WHO's standard Completely eliminate viruses, bacteria, germs, and VOCs

INNOVATIVE AIR STERILIZED EFFECTS FROM THE NATURE

OH Radical (Hydroxyl Radical)

REFLECT THE PRINCIPLE OF PURIFYING SYSTEM IN THE NATURE

NATURALLY GENERATE FROM SUNLIGHT, OZONE, AND WATER 99.9% REMOVE VIRUS, BACTERIA, GERMS, AND POLLUTANTS





WHY AIR STERILIZER AIRVACCINE015+?







ELIMINATE VIRUS 99,9%





REMOVE ODORS LARGE EFFECTIVE AREA



HARMLESS





Point



UK DOD ORIGINAL MILITARY TECHNOLOGY

Strong air disinfection system for preparing bio chemical warfare to remove toxic gases, infectious disease, respiratory allergies, viruses, and bacteria



ERADICATE 99% OF VIRUSES AND BACTERIA

Completely remove 0.001 micrometer viruses and VOCs through chemical decomposition



COMPLETELY HARMLESS TO HUMAN, PLANTS AND ANIMALS

The level of ozone emissions is lower than WHO environmental standard (0.05ppm)



LARGE COVERAGE AREA

Cover 120m² maximally



ODOR REMOVAL

Help to remove any odors from VOCs, smoke, foods, and pets



LOW MAINTENANCE COSTS

Electric charges will be around 40 cents per a month when using 24/7





ERADICATE 99% OF VIRUSES AND BACTERIA

Completely remove 0.001 micrometer viruses and VOCs through chemical decomposition








ODOR REMOVAL

Help to remove any odors from VOCs, smoke, foods, and pets






LOW MAINTENANCE COSTS


Electric charges will be around 40 cents per a month when using 24/7



IS MY HOME SAFE?

Indoor contaminants cannot be removed by cleaning.





VARIOUS USAGES OF AIRVACCNIE 015+

Excellent utilization of AirVaccine015+ in anywhere



Home where children with a weakened immune system live



Home where seniors with respiratory diseases live



Who suffers from atopy and allergic rhinitis



Where a number of pathogenic bacteria live such as an operating room, a doctor's office, and a waiting room in the hospital



Who suffers from sick house syndrome



Who has troubles with fur allergies by pets



Pregnant woman who need a protection from viruses



Students who need some fresh air to study




AIRVACCINE 015+ CAN TIDILY INSTALL ON THE WALLS



AIRVACCINE 015+ Active OH Radical Disinfection


DETAILS ON AIRVACCINE015+



HOW TO USE / CHANGE CARTRIDGE

TO PREPARE TO USE THE CARTRIDGE


- Open the upper cover of the cartridge, and remove the label on top of the solution container.
- Close the upper cover.





TO INSTALL / CHANGE THE CARTRIDGE

- Open the cartridge cover and insert the cartridge deep inside the main body.
- When the cartridge is properly installed, you get the beep, and the red cartridge alarm indicator is turned off. The product stays in off mode.
- Press the power button, then the product starts non



SHOW CARTRIDGE REPLACEMENT INTERVALS / HOW TO RESET

- If the cartridge change indicator blinks in blue you need to change the cartridge. If you do not change the cartridge, the blue indicator stops blinking, and the product stops operating.

- Install new cartridge and press level button for 3 seconds

- When you get beep and the cartridge change indicator turns off, the re-set is completed.




AIRVACCINE 015+
Active-OH Radical Disinfection





PRODUCT SPECIFICATION	AIR DISINFECTION SYSTEM
MODEL	AIRVACCINE015+
POWER CONSUMPTION	2.4 Watt
NOISE	MAXIMUM 35dB
OPERATIONAL AREA	120m²
INSTALLATION PLACE	INDOOR USE
WEIGHT	1.42 KG (3.13 lb)
SIZE	345W X 136L X 241H (mm)
ELECTRICAL APPLIANCES SAFETY CERTIFICATION	HU10777-14001A(2014.07.14/Adaptor
ELECTROMAGNETIC WAVES SAFETY CERTIFICATION	MSIP-REM-EYM-AirVaccine015(2015.6.2)
CONFORMANCE TEST REPORT	KC 60335-2-65 /15-029854-01(2015.07.27 / Ozone concentration)





FRONT SIDE













Active · OH Radical Disinfection


Test Results on AirVaccine015+

- H1N1 VIRUS, INFLUENZA 98.3%
- CORONA TYPE VIRUS (SARS)
- COLON BACILLUS: 99,9%
- PSEUDOMONAS AERUGINOSA: 99.9%
- STAPHYLOCOCCUS AUREUS: 99.9%
- BACILLUS SUBTILIS: 99.9%


- DEODORIZE AMMONIA: 95%
- DEODORIZE TOLUENE: 95%
- DEODORIZE FORMALDEHYDE: 95%

*TEST ENVIRONMENT: 8m3 CHAMBER

(Proven excellent performance by testing 8 times bigger chamber than others)







TEST RESULT ON DEODORIZATION BY KCL

시험 결과

TEST RESULT ON ATTACHED BACTERIA BY KOL

시험성적서

STREET LAND CO. 51.9

1.7 × 10*

STAL NOTES ADDING NEED AREA Stumb Stumb NO

99.9

99.9

*----kcl

世군시회

田敷

발균시험


문에 의한 한 제품도 없다

西京州市第二日19-00回

6. 化聚溴法 1.19年被約


BLANK







TEST RESULT BY GANGWON UNIVERSITY

TEST RESULT BY GANGWON UNIVERSITY











Selected as an Excellent enterprise for atopic prevent environment, and obtain Certification mark on atopic safety, and Certification mark on atopic quality the world's first among air sterilizers.

Those are international certifications from World Atopy Association, which is based on New York in USA and related to the World Health Organization (WHO) and world environment organizations.